

nexa3D®

Introducing Nexa3D's brand new material cartridge! We've completely redesigned this cartridge to increase material capacity, enhance sealing performance and increase vat filling speeds.



- A larger 1.5L / 1.5Kg capacity means you can save time and print longer between material changeovers
- 2-4X faster vat fill speeds so you can start printing quickly
- Improved sealing performance for easier material storage between uses
- Enhanced and assured connection with a new vat spout
- Downloadable bottle holder and cap grip files for easy storage and use

Before using the new material canister perform the following:

1. Remove the old resin spout from the XiP / XiP Pro vat and replace it with the new provided resin spout.
2. Shake the material canister before inserting it into XiP / XiP Pro for use.
3. Remove the top sealing cap
4. Insert the bottle into the machine until the bottle latches on to the new spout as shown.



Learn more and download our free STL cartridge holder and cap files today!